


Preassembled center screw on air bellow 3045

In use at following air suspensions: GL70L, GL70 and GL70 HD


Delivery of air bellow 3045:

- The center screw will preassembled till the micro-encapsulation starts to lock. The air bellow and plastic piston are orientated. With loosen the center bolt a little resistance will be recognized.



Delivery of air bellow 3045 with adapter plate:

- Air bellows with adapter plate will be delivered preassembled with the correct tightening torque.



Notice:

In combination with changing over to preassemble the micro-encapsulate center screw, we create new material numbers for the sets at the OEM and OES. The new material numbers you will find at the spare part data sheet.

The tightening torques for the center bolts and screwing of the adapter plate with the spring you can find in the assembling guidelines.